



FLOORING SURFACES INSTALLATION/TROUBLESHOOTING

FLOOR PREPARATION

DO:

- Wash floor 2-3 times with lukewarm water before using.
- For special non-slip requirements or treatments see page 23 or call our technical support.

DO NOT:

- Use alcohol, ammonia, acetone, bleach or solvents to clean surface.

LONG TERM SEMI-PERMANENT INSTALLATION

REUSE IT

Do-it-yourself installation instructions are included with every order and are available online at www.aesonflooring.com.

PERMANENT INSTALLATION

Professional installation recommended. Complete instructions are included with each container of Aeson adhesive. Seams should be double cut by a professional. Chemical welding is not recommended. Heat welding is not necessary. Aeson carries heat welding rod material in all colors if you wish a seamless floor.*

If you have any questions, call us at 800-523-0960 or email info@aesonflooring.com.

AESON is not responsible for costs related to the delay, damage or installation of its flooring.

*Seamless does not mean invisible. Heat welding prevents moisture from penetrating the seam and destroying the adhesive.

Aeson Flooring offers an Installation Booklet available both online at www.aesonflooring.com and at 800-523-0960.

TEMPERATURE

Variations in temperature can have a negative impact on installation, non-slip characteristics and how fast the floor gets dirty. Warm air holds moisture; cool air releases moisture. During the day most facilities become warmer due to body heat. At night, the temperature drops due to no bodies, plus the thermostat is usually turned down. In the morning, the moisture held by the warm air has settled on the floor along with all the dust and dirt that had been stirred up during the day. The combination of these two factors create slippery floors which are prone to develop scuff marks.

CONTRIBUTING PROBLEMS

Doorways that open directly to the outside invite dust, pollen, and contaminants into your workspace.

Note: Most floors need weekly cleaning with a detergent/degreaser. (Proclean - see this page.)

The best way to pick up scuff and dye marks is to use a floor machine with brushes.

Aeson offers Slip NoMor Finish that protects the floor, keeps it non-slip and makes it easier to clean.

HANDLING & STORING YOUR FLOOR

Store in a dry, clean, protected space. Temperature should be between 55 and 80 degrees. Floors should be wrapped around a rigid tube with a diameter of at least 4 inches (6 inches is better). Floors should be stored on end.

Information on this specification sheet supersedes all materials published prior to April 2011.